

B6.4d

- Dismantle & Clean
- Refill Shocks 350cst rear 375 front
- Change Springs
- fit roll bar on rear
- Set rear wing to 0°
- fit gear diff - rebuild with
ok diff fluid
- refit water fall brace
- remove ackerman shim
- refit front wing with one piece
butter
- fit Avid -2° c clamp, Pills to:
 - rebuild ball
diff
 - Touch up bodies
- Toe In -1°
- Pin height +0.7mm
- Anti Squat 1.0°